



## CLEANING TANKS

All tanks to be utilized on the application of **Quick-Sol** must be freed of all chemical residues.

Prior to filling the tank with **Quick-Sol**; such must be rinsed with fresh water and then flushed empty.

For tanks used to apply other chemical; the proper cleaning procedures must be followed.

After all conventional cleaning procedures are followed; a visual inspection of the tanks must be performed.

If a visual inspection reveals the presence of any residues on the interior of the tanks, then:

1. Tanks must be filled to capacity with a mixture of water and **Quick-Sol** (1 Gal **Quick-Sol** /100 Gal Water)
2. Let the mixture sit in the tank for at least 2 hours.
3. Flush out the mixture from the tank(s)
4. If any residue is still present; repeat steps 1 through 3.